

FIG. 1




FIG. 2




FIG. 3





FIG. 4




FIG. 5




FIG. 6 High Level Classes in Disc Application




FIG. 7 EntityLocator Implementation




FIG. 8 Starting and Running the DiscEntityServer





FIG. 9 Initialization of the EntityLocator




FIG. 10 An Iteration in the Location Process




FIG. 11 StatusMonitor




FIG. 12 Discovering and Updating a Responder




FIG. 13 DiscConfig communications methods




FIG. 14 Changing the configuration values




FIG. 15 GUI initialization




FIG. 16 Directory Initialization




FIG. 17 Building the Directory




FIG. 18A Fetching the list of NetworkEntities





FIG. 18B Telling the DiscEntityServer to Rescan the network




FIG. 18C Clearing the storage of all found NetworkEntities



5000

HiNet RC 3000 Management - Netscape
File Edit View Go Communicator Help

Back Forward Reload Home Search Netscape Print Security Stop

Project Search and Info Manager Links VISUAL BASIC Writing IP Mult Netbeui-PC We Premier Service Win32De

Bookmarks Location: <http://gonefishing.eng.sc.rolm.com/tol/mgmt/> What's Related

SIEMENS 5006 HiNet RC 3000 Management

© 1998 Siemens AG, All Rights Reserved
© 1999 Siemens Information and
Communication Networks, Inc., All rights reserved

Summary

Type: h.323 Client
User: proxy1
IP Address: 165.218.33.89
Hostname: gonefishing.eng.sc.rolm
Administrative Links:
[View Events](#)
[Access Configuration](#)

Commands
[Refresh](#) 5018 Immediately refreshes the view
[Rescan](#) 5020

Directory

Hardware View 5010
Software View 5012
Server Software 5014
H.323 Clients 5016
5016a
proxy1's HiNet RC 3000 Client
alexglazov's HiNet RC 3000 Client
markc's HiNet RC 3000 Client
HiNet RC 3000 Client
eddiel's HiNet RC 3000 Client
samsonw's HiNet RC 3000 Client

Login / Logout

View Network

View Map
Current Users
Current Calls

View Events

System Administration

Configure Network
General System
Emergency Alias
Dialing Prefixes
License Admin

User Administration
List Users

FIG. 19A



5000




FIG. 19B



5000




FIG. 19C



5000




FIG. 19D



5000

HiNet RC 3000 Management - Netscape

File Edit View Go Communicator Help

Back Forward Reload Home Search Netscape Print Security Stop

Bookmarks Location: <http://gonefishing.eng.sc.rohm.com/tol/mgmt/>

Stanford Univer Rec.humor.funny Siemens Santa C Enterprise Netw Santa Clara PM_ WWW Search

SIEMENS 5006 HiNet RC 3000 Management

Login / Logout

View Network

- View Map
- Current Users
- Current Calls

View Events

System Administration

- Configure Network
 - General System
 - Emergency Alias
 - Dialing Prefixes
 - License Admin

User Administration

- List Users
- Create User
- User Defaults
- Admin Self

Home Page

Help

Current IP address ranges

139.82.10.42	- 139.82.10.42
165.218.32.117	- 165.218.32.117
165.218.32.131	- 165.218.32.131
165.218.22.27	- 165.218.22.27

Remove Remove All

Add IP Range

Start of Range:

End of Range:

Clear Add

Runtime Configuration

Minutes between automatic rescans:

Days until old components are removed:

Set Reset

Actions

Rescan (w/o Clear)

Rescan (w/Clear)

Pause

Status Messages

Document: Done

FIG. 19E